

# How to Open Rieke Caps

1. Pull up on each side of the gray tabs.



2. Pull up on the gray tabs until the clear spout is fully raised.



3. Twist off the outer gray cap.



4. Pull clear tab out from spout.

